


1088-240322-V2 - SP Window FLB - Assembly instructions


General view

Dimensions in millimeters

1st step



2nd step




1088-240322-V2 - SP Window FLB - Assembly instructions

General view

Dimensions in millimeters

3rd step - horizontal or vertical



1088-240322-V2 - SP Window FLB - Assembly instructions

General view

Dimensions in millimeters

4th step - optional as available

